To search for a code for your TV:

1. Turn on your TV.

2. On the remote control, press TV once, it will blink once. Then press and hold SETUP until the TV key blinks twice.

3. Type **9 9 1**. The TV key will blink twice.

4. Aim the remote control at the TV and press POWER once.

5. Now press and release the CH+ key continuously, then stop when the TV turns off.
   Note: In the search mode, the remote control will IR codes from its library to the selected device, starting with the most popular code first.

6. Press POWER. The TV should turn on.
   Note: If the TV does not turn on during step 6, then slowly press and release CH- to go back through the codes, then press SETUP when the TV turns on.

7. Press SETUP once to lock in the code. The LED will blink twice to indicate that the code is saved.

Need help? We're happy to get you get connected.

Call us
(519) 839-4734
Mon-Fri 8:30am-4:30pm EST

Email us
info@gosfieldtel.ca
24/7

Live Chat
gosfieldtel.ca
Mon-Fri 8:30am-4:30pm EST